How to load money on your Laundry Card

Step 1 : Place and hold Laundry Card to Payment Terminal.



Step 3 : Tap amount. Then tap Confirm.





Step 2 : Current Laundry Card balance is displayed. Tap Credit Card button.



Step 4 : Insert/Swipe/Tap your Credit/ Debit Card to Payment Terminal.



Step 5 : Place and hold Laundry Card to Payment Terminal to complete transaction.

